



1. SELECT TWO ROTOR <sup>(BUS)</sup> INPUTS, (8 WIRE EACH) (SPST PUSH BUTTON).
2. ONE ROTOR BUS OUTPUT,
3. DIGITAL CONTROL BUS OUTPUT.
4. POWER/ON/OFF (SPST PUSH BUTTON)
5. ROTOR SELECT SWITCH (MOMENTARY PUSH SWITCH) RS-
6. ROTOR SELECT INDICATOR, (LEDS) FLASHING.



FRONT



DATE 20/SEP/87	SUJET SUBJECT ROTOR SELECTOR UNIT. SPECS.	FEUILLE SHEET 3 DE OF 11
DESSINE DRWG BY AER		NO REF. JOB NO. -
VERIFIE CHKD BY -	<b>ROBOT TELECOMMUNICATIONS</b>	ECHELLE SCALE -